

## Determination of the Radon Diffusion Coefficient and Radon Diffusion Length of a specimen

**Client:** DOYMA GmbH & Co  
Dichtungssysteme  
Brandschutzsysteme  
Industriestraße 43-57  
28876 Oyten

**Project:** Determination of the Radon Diffusion Coefficient and  
Radon Diffusion Length of a sealing system  
"Quadro-Secura® Quick G"

**Project number:** 190416-08

**Contractor:** IAF-Radioökologie GmbH

**Prepared by:** Dipl.-Ing. (BA) R. Baumert

Radeberg, 26. June 2019



Dr. rer. nat. habil. Hartmut Schulz  
Managing Director



The accreditation is valid for the measurement results of the radon concentration indoors (SOP 4-02, 2018-11). The assessments made are based on this measurements results.

Wilhelm-Rönsch-Str. 9  
01454 Radeberg  
Fon +49 (0) 3528 48730-0  
Fax +49 (0) 3528 48730-22  
E-Mail [info@iaf-dresden.de](mailto:info@iaf-dresden.de)

Managing Directors:  
Dr. rer. nat. habil. Hartmut Schulz  
Dr. rer. nat. Christian Kunze  
Dipl.-Ing. (BA) René Baumert  
Trade register: HRB 9185  
Register court: Dresden

Bank account:  
HypoVereinsbank Dresden  
IBAN: DE92 8502 0086 5360 1794 29  
SWIFT (BIC): HYVEDEMM496

## 1 Task

According to the order issued by DOYMA GmbH & Co, the Radon Diffusion Coefficient of the sealing system "Quadro-Secura® Quick G" has to be determined by the IAF-Radioökologie GmbH (IAF) and an assessment has to be made regarding the "radon tightness" of the material.

## 2 Methodological framework

In order to determine the radon diffusion values, the specimen was installed in a two chamber measuring system in such a way that radon can migrate from chamber 1 into chamber 2 only if it traverses the sealing system as a result of a diffusion process. The radon concentration developing in chamber 2 is recorded at one-hour intervals. Depending on the radon tightness of the sealing system, the increase in radon concentration in chamber 2 varies, resulting in a plateau value, which forms a steady state between radon migration from the radon reservoir (chamber 1) through the sealing system and radon decay in the measuring chamber (chamber 2) and thus determines the radon diffusion coefficient  $D$ , measured in  $[m^2/s]$ . The diffusion length  $L_D$  of the specimen is given by

$$L_D = \sqrt{\frac{D}{\lambda_{Rn}}},$$

with  $\lambda_{Rn} = 2,1 \cdot 10^{-6} / s$  being the radon decay coefficient. The radon diffusion length  $L_D$  is the average length a radon atom passes through the test specimen during its half-life. A sealing system is to be rated as "radon-tight" if the material thickness ( $d$ ) is at least three times its radon diffusion length  $L_D$ .

$$R = \frac{d}{L_D} \geq 3,$$

Otherwise the material is rated as "not radon tight".

## 3 Results and assessment

The radon diffusion length calculated from the measurement results and the results of the "radon tightness" are summarized in Table 1.

Table 1: Results of the test for radon tightness

Sealing material	Material thickness of the specimen [d]	Diffusion coefficient [D]	Diffusion length [ $L_D$ ]	Test parameter $R = d/L_D$	Result
"Quadro-Secura® Quick G"	80 mm	$4.29 \cdot 10^{-10} m^2/s$	14.29 mm	5.6	<b>R &gt; 3, radon-tight</b>

The result "radon tight" also applies to the sealing systems Quadro-Secura® Quick H, Quadro-Secura® Quick X und Quadro-Secura® Quick O.